

Stc-3028 (没有说明书，详情见如下详情明细)

1. control temperature and humidity at the same time.
2. connect with humidifier and dehumidifier equipment at the same time.
3. connect with refrigeration/ heating and humidifier/dehumidifier equipment at the same time.

STC-3028 AC110-220V Dual Display Dual Temperature Adjustable Temperature Controller with 1M Cable

Specification:

Model: STC-3028

Input voltage: AC110~220V± 10%

Measuring temperature range: -20°~+80°

Measuring humidity range: 00%RH~+100%RH

Accuracy: ±1°, 0.1%RH

Relay output contact capacity: 10A/240VAC

Sensor length: 1m

Set startup temperature(humidity): Press the "up" button once to display the starting temperature(humidity). Long press the "up"

button for about 3 seconds,The required temperature(humidity) can be set by the up and down keys

Set stop temperature(humidity): Press the "down"button once to display the stop temperature(humidity). Long press the button for

about 3 seconds and the stop temperature(humidity) number flashes. The required temperature(humidity) can be set by the up and down keys

Temperature/humidity correction: Press "up" and "down" button at the same time.